


EH4000 Breakdown



Description

Part

Description

Part

A	1/2" Ball Valve (Shut off)	BV-050	K	2nd Stage Replacement Element	DE401
B	1/2" Nipple	AB032-1/2	L	2nd Stage O-ring	N32-95-256
C	1st Stage Head Assembly	WIL-040	M	2nd Stage Bowl	N34-15-180
D	1st Stage O-ring	N32-95-257	N	Manual Petcock Drain	PC-03
E	1st Stage Replacement Element	4P-060	O	Indicator Assembly (Moisture)	RTi-04-CK
F	1st Stage Bowl Ring (only)	WIL-035	P	Indicator Eye with Paper	RTi-SG-651
G	Bowl Assembly w/ Drain	N34-95-201	Q	1/2" to 1/4" Reducer	AB035-1/2-1/4
H	Auto Drain	N32-95-979	R	1/4" Regulator	R79
I	2nd Stage Head Assembly	WIL-001M	S	1/4" Nipple	AB032-1/4
J	2nd Stage Bowl Ring (only)	WIL-013	T	Pressure Gauge 160 PSI	PG-160

